

ECONSPRAYER / SPRAY GUN SPARE PARTS LIST

(MIE)

NO	CODE NO	DESCRIPTION
1	MIE/2 (R)	Cap For Valve Body (Red)
2	MIE/2 (Y)	Cap For Valve Body (Yellow)
3	MIE/2 (W)	Cap For Valve Body (White)
4	MIE/3	Main Valve Body
5	MIE/3CPT(1/8G)(W) PT	Main Valve Body Complete
6	MIE/3CPT(1/8G)(Y) PT	Main Valve Body Complete
7	MIE/3CPT(SG)	Main Valve Body Complete
8	MIE/4	Spring For Valve Body
9	MIE/5	Ball Bearing (Big)
10	MIE/6	Valve Body (Small)
11	MIE/6CPT	Small Valve Body Complete (No.6, 9, 10) Washer For Small Valve (No. 8)
12	MIE/7	Washer For Small Valve
13	MIE/8	Valve Control Cap
14	MIE/9	Ball Bearing (Small)
15	MIE/10	Cup Leather
16	MIE/10CPT	Cup Leather & Holder (No.11 & 13)
17	MIE/11	Cup Leather Holder
18	MIE/12	Spring For Cup Leather
19	MIE/13	Nozzle Tip Holder
20	MIE/13CPT (PT)	Nozzle Tip Holder CPT (No.15 & 17)
21	MIE/14(P)	Nozzle Tip
22	MIE/16R	Rubber Q Ring
23	MIE/16	Vortex Holder
24	MIE/17	Vortex Body
25	MIE/18 (Y)	Handle (Yellow)
26	MIE/18 (W)	Handle (White)
27	MIE/19	Pin For Handle
28	MIE/20CR	Hose Clip
29	MIE/20CPT(SG) (80H)	Rising Tube Complete (No.23,26,28,30,31)
30	MIE/20CPT (80H)	Rising Tube Complete (No.23,27,28,30,31)
31	MIE/20(SG)	Rising Tube (SG)
32	MIE/20 (1/8G)	Rising Tube (1/8G)
33	MIE/21	Filter Mesh For Strainer
34	MIE/22CPT (80H)	Rising Strainer Holder Cpt (No.28, 30, 31)
35	MIE/22	Rising Strainer Holder
36	MIE/23	Cover For Strainer
37	MIE/33K-3.5"	Spraying Lance For Cocoa
38	MIE/33K-6.5"	Spraying Lance For Cocoa
39	MIE/33L-3.5"	Spraying Lance For Lubrication
40	MIE/33L-6.5"	Spraying Lance For Lubrication
41	MIE/33	Spraying Lance

Remark

SG

SPRAY GUN



Complete set item / Component

KNAPSACK SPRAYER SPARE PARTS LIST

PB-16 AND PB-20 WITH (P1) AUTOMATIC RELEASE (New Version)

NO	CODE NO	SAME AS CODE NO	DESCRIPTION
1	LSA / 4 /1	LSA/4/1	NOZZLE CAP
2	LSA / 4	LSA / 4	LIQUID SPRAY ADJUSTABLE NOZZLE
3	TE / 2AC (P)	TE / 2AC (P)	LOCK NUT
4	TE / 2A (P1)	TE / 2A (P1)	TWIN ELBOW
5	333 W	MB/45 W	WASHER
6	331	MFB/46-18"	SPRAYING LANCE
7	332 W	MB/47W	WASHER (345 W)
8	321 / CPT (P1)	~	
8(a)	321 (P1)	MB/41CPT(P1)	P1 AUTOMATIC RELEASE COMPLETE
9	323 (P1)	MB/43 (P1)	P1 LEVER FOR AUTOMATIC RELEASE
10	323 A	MB/42A	PIN
11	324	MBP/44	FIXTURE CLIP FOR LEVER NO. 323 (P1)
12	321 R	MB/58R	P1 'O' RING 116
13	321 A (P1)	MB/41(P1)	P1 RELEASE BODY
14	345 W	MB/47W	WASHER
15	ADT / 321 (P1)	ADT/41/46A-02(F)PA	P1 ADAPT. FOR AUTO. RELEASE TO LANCE
16	325 R	MB/40R(N)	RUBBER 'O' RING 008
17	325	MB/40A	SPINDLE
18	326	MB/39A	RUBBER DISC FOR NO. 327
19	327	MB/38A(P)	VALVE
20	328	MB/37A	SPRING FOR AUTOMATIC RELEASE
21	329 W	MB/36W(A)	WASHER FOR PLUG
22	330	MB/35A(P)	PLUG FOR AUTOMATIC RELEASE
23	346 (P1)	MB/55CPT(P1)	P1 RUBBER HOSE C/W CHAMBER & UNION
24	322 (P1)	MB/59S(P)	P1 STRAINER FOR CHAMBER
25	341 (P1)	MB/59(P1)	P1 CLEANING CHAMBER
26	342	MB/55CR 'MOO'	HOSE CLIP (MOO)
27	340	MB/55	RUBBER HOSE
28	344	MB/53P	UNION
29	343	MB/54P	NIPPLE FOR HOSE
30	345 W	MB/47W	WASHER
31	304	MBP/1CP	STAND GUARD
32	312 / CPT	MBP/24CPT(P)	SUCTION VALVE COMPLETE
33	310	MBP/24 P	RISING TUBE
34	320 W	MB/20W	WASHER
35	311	MB/17	BALL BEARING
36	312	MB/22 P	SUCTION VALVE BODY
37	312 W	MB/22W	WASHER
38	318	MB/21P	SCREW
39	317 W	MB/20W	WASHER
40	315 / CPT	MBP/18CPT (PA)	PUMP CYLINDER COMPLETE
40(a)	315SHA	MBP/15SHA	Bracket
40(b)	315SHB	MBP/15SHB	Screw of Bracket
40(c)	315SH	MB/15SH	Pump Cylinder Holder
40(d)	315SHW	MBP/15SHW	Lock Washer
41	317 W	MB/20W	WASHER

KNAPSACK SPRAYER SPARE PARTS LIST

PB-16 AND PB-20 WITH (P1) AUTOMATIC RELEASE (New Version)

NO	CODE NO	SAME AS CODE NO	DESCRIPTION
42	319	MB/25P	AIR CYLINDER COMPLETE
43	315 W	MB/16W-1	SPRING WASHER
44	315 S	MB/16-1	SCREW
45	309	MB/30	NUT FOR PISTON
46	308	MB/31	WASHER FOR PISTON (LOWER SIDE)
47	307	MB/32	PISTON
48	314	MB/14 P	MILLED NUT FOR PUMP CYLINDER
49	306	MB/33 (2G)	PISTON ROD BRASS WASHER (UPPER SIDE)
		MB/33VC	
50	305	MB/34	NIPPLE FOR PISTON ROD
51	306/CPT	MFB/33CPT(2G)	PISTON ROD COMPLETE
52(a)	313A	MB/29A	PIN (IR) (3/32" X 5/8")
52(b)	313C	MB/29C	PIN (3/32" X 3/4")
53	MB/63(P)	MB/63(P)	LANCE LEVER CLIP (OPTIONAL)
54	313	MFB/28	PULL BAR
55	313 B	MB/29B	PIN (1/8" X 5/8")
56	303	MB/7P(S)	STRAINER
57(a)	301	MBP/8	COVER OF TANK
		MBP/8CPT(P1)	COVER OF TANK C/W Rubber Ring
57(b)	301R	MBP/08AR-1	COVER RING
58	347 (A)	MFB/13 (A)	Pump Handle Complete with Hand Sleeve
59	337 / CPT	MBP/11F-02	Shoulder Strap Complete (Per Pair)
60	338	MB/12B	STRAP HOLDER
61	337	MBP/11F-2	SHOULDER STRAP Only (Piece)
62	339	MBP/10	HOOK (PER PAIR)
63	MB/11B	MB/11B	Plastic Pad for Shoulder Strap (Optional)
64	MB/61-02(PB9)	~	WASHERS + LSA/4/1(R)
65	MBP/62-02(P1)BM# 1	~	ACCESSORIES IN PACKAGE
66	MB/W-01(P1)#1	~	WASHER SET
67	MB/W-01(P1)	~	WASHER SET

REMARK



Combination item



Complete set item / Component